

## Steering Stabilizer Chassis Guide

Click on Order # to Order

**Order Stabilizer AND Bracket Kit (Where Required)**

[Return to Steering Stabilizers](#)

### Class A Motorhomes (Use Stabilizer RSSA, # 96-1101)

Chassis	Year	Part #	Order #
Ford F53, V10	00-11	RBK9	<a href="#">96-1326</a>
Ford F53, V8	89-08	RBK4	<a href="#">96-1113</a>
Workhorse W18/16	06-09	RBK12	<a href="#">96-1398</a>
Workhorse W20/22/24	00-09	RBK13	<a href="#">96-1117</a>
GMC/Kodiak C4500/5500	03-10	RBK5	<a href="#">96-1114</a>
Monaco (except Dana Spicer Front axle)	All Years	RBK6	<a href="#">96-1115</a>
Freightliner XC	95-05	RBK14	<a href="#">96-1118</a>
Freightliner Solid Front Axle	06-08	RBK18	<a href="#">96-1124</a>
Spartan EC2000	93-07	RBK6	<a href="#">96-1115</a>
Spartan Mt. Master, non-ifs	93-07	RBK7	<a href="#">96-1116</a>
Spartan, WC Series	99-06	RBK7	<a href="#">96-1116</a>
Country Coach Intrigue	94-98	RBK10	<a href="#">96-1340</a>

### P30 Motorhomes W/O Damper (Use Stabilizer RSSP30, # 96-1103)

P-series (w/o OEM damper)	81-05	RBK3	<a href="#">96-1112</a>
---------------------------	-------	------	-------------------------

### P-Series Motorhomes With OEM Damper (Use Stabilizer, # 96-1107)

**Stabilizer mounts in place of damper. Has 'return-to-center'. NO BRACKETS NEEDED.**

GMC P30/32/3500	98-06	RSSCP30	<a href="#">96-1107</a>
Workhorse P30/32/35	00-05	RSSCP30	<a href="#">96-1107</a>

### P-Series Motorhomes With OEM Damper (Use Stabilizer, # 96-1108)

**Stabilizer mounts in place of damper. NO 'return-to-center'. NO BRACKETS NEEDED.**

GMC P30/32/3500	98-06	RSDP30	<a href="#">96-1108</a>
Workhorse P30/32/35	00-05	RSDP30	<a href="#">96-1108</a>

**Class C Motorhomes (Use Stabilizer RSSC, # 96-1100)**

Ford E350/450 V10	87-08	RBK11	<a href="#">96-1341</a>
Ford E350/450 V8 (w/o OEM damper)	87-09	RBK2	<a href="#">96-0111</a>
GMC 1500/2500/3500 (w/o dual cross members)	04-08	RBK17	<a href="#">96-1121</a>
GMC G30 Cutaway	71-95	RBK1	<a href="#">96-1110</a>

**Trucks and Vans (Use Stabilizer RSSB, # 96-1111)**

Ford F250/350 4WD	99-07	RBK16	<a href="#">96-1120</a>
Dodge 2500/3500	03-08	RBK20	<a href="#">96-1122</a>