

# Custom Harnesses for Tekonsha Brake Controllers



Some modern vehicles with towing packages come with a trailer connector under the dash. Harnesses may be purchased to connect directly into these connectors and into the back of the Prodigy or Primus brake control. This greatly simplifies installation as there is no tapping into your vehicles' wiring system.

**Note:** Vehicles that are not pre-wired with under-dash plug-ins must be wired with the harness that comes with the brake controller.

Make	Year	Model	Inst.Time	Part #	Mfg. #
Buick	2008 - 2012	Enclave, w/Factory 7-Way	5 min	<u>96-3026</u>	3026-P

Make	Year	Model	Inst.Time	Part #	Mfg. #
Cadillac	2002	Escalade, All, Inc. EXT	5 min	<u>96-8318</u>	3025-P
Cadillac	2003 - 2006	Escalade, All, Inc. EXT & ESV	5 min	<u>96-3015</u>	3015-P

Make	Year	Model	Inst.Time	Part #	Mfg. #
Chevrolet	2003 - 2006	Avalanche, All Styles	5 min	<u>96-3015</u>	3015-P
Chevrolet	2002	Avalanche, All Styles	5 min	<u>96-8318</u>	3025-P
Chevrolet	1999 - 2002	Pickup, Silverado, All Styles	5 min	<u>96-8318</u>	3025-P
Chevrolet	2003 - 2006	Pickup, Silverado, All Styles	5 min	<u>96-3015</u>	3015-P
Chevrolet	2007	Pickup, Silverado, Classic Only	5 min	<u>96-3015</u>	3015-P
Chevrolet	2003 - 2006	Suburban, All Styles	5 min	<u>96-3015</u>	3015-P

Chevrolet	2000 - 2002	Suburban, New Body Style w/Amber Turn Signals	5 min	<u>96-8318</u>	3025-P
Chevrolet	2003 - 2006	Tahoe, All Styles	5 min	<u>96-3015</u>	3015-P
Chevrolet	2000 - 2002	Tahoe, New Body Style w/Amber Turn Signals	5 min	<u>96-8318</u>	3025-P
Chevrolet	2009 - 2012	Traverse, w/Factory 7-Way	5 min	<u>96-3026</u>	3026-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Chrysler	2007 - 2009	Aspen, w/Factory Tow Package	5 min	<u>96-8327</u>	3020-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Dodge	1997 - 2011	Dakota Pickup, w/Factory Tow Package	5 min	<u>96-8327</u>	3020-P
Dodge	1998 - 2009	Durango, w/Factory Tow Package	5 min	<u>96-8327</u>	3020-P
Dodge	2011 - 2012	Durango, w/Factory Tow Package	5 min	N/A	3045-P
Dodge	1995 - 2009	Pickup, Ram, Full Size, 1500 Only, All Models	5 min	<u>96-8327</u>	3020-P
Dodge	2010 - 2012	Pickup, Ram, Full Size, 1500 Only, All Models	5 min	<u>96-3021</u>	3021-P
Dodge	2010 - 2012	Pickup, Ram, Full Size, 2500 HD Only, All Models	5 min	<u>96-3021</u>	3021-P
Dodge	1995 - 2009	Pickup, Ram, Full Size, 2500 Only, All Models	5 min	<u>96-8327</u>	3020-P
Dodge	2010 - 2012	Pickup, Ram, Full Size, 3500 HD Only, All Models	5 min	<u>96-3021</u>	3021-P
Dodge	1995 - 2009	Pickup, Ram, Full Size, 3500 Only, All Models	5 min	<u>96-8327</u>	3020-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Ford	1994 - 1996	Bronco, Full Size	5 min	<u>96-8313</u>	3035-P
Ford	1992 - 2008	E-150 Econoline Van, Full Size, All Models	5 min	<u>96-8313</u>	3035-P
Ford	2009 - 2012	E-150 Econoline Van, Full Size, All Models	20 min	<u>96-3034</u>	3034-P
Ford	1992 - 2008	E-250 Econoline Van, Full Size, All Models	5 min	<u>96-8313</u>	3035-P

Ford	2009 - 2012	E-250 Econoline Van, Full Size, All Models	20 min	<u>96-3034</u>	3034-P
Ford	1992 - 2008	E-350 Econoline Van, Full Size, All Models	5 min	<u>96-8313</u>	3035-P
Ford	2009 - 2012	E-350 Econoline Van, Full Size, All Models	20 min	<u>96-3034</u>	3034-P
Ford	1992 - 2008	E-350 Econoline Van, RV Cutaway w/Factory Tow Prep Plug	5 min	<u>96-8313</u>	3035-P
Ford	2009 - 2011	E-350 Econoline Van, RV Cutaway w/Factory Tow Prep Plug	20 min	<u>96-3034</u>	3034-P
Ford	1992 - 2008	E-450 Econoline Van, RV Cutaway w/Factory Tow Prep Plug	5 min	<u>96-8313</u>	3035-P
Ford	2009 - 2011	E-450 Econoline Van, RV Cutaway w/Factory Tow Prep Plug	20 min	<u>96-3034</u>	3034-P
Ford	2000 - 2005	Excursion, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	1997 - 2011	Expedition, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2002 - 2010	Explorer, w/Factory Tow Package	5 min	<u>96-8313</u>	3035-P
Ford	2011 - 2012	Explorer, w/Factory Tow Package	5 min	<u>96-8313</u>	3035-P
Ford	2004	F-150 Light Duty Heritage, Flareside Old Body Style	5 min	<u>96-8313</u>	3035-P
Ford	2004	F-150 Light Duty Heritage, Styleside Old Body Style	5 min	<u>96-8313</u>	3035-P
Ford	1997 - 2003	F-150 Light Duty, Flareside	5 min	<u>96-8313</u>	3035-P
Ford	1997 - 2003	F-150 Light Duty, Styleside	5 min	<u>96-8313</u>	3035-P
Ford	2000 - 2003	F-150 SuperCrew, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2004 - 2008	F-150 SuperCrew, New Body Style	5 min	<u>96-8313</u>	3035-P
Ford	2009 - 2012	F-150 SuperCrew, New Body Style, w/5.5 & 6.5 ft. Beds	20 min	<u>96-3036</u>	3036-P
Ford	1994 - 1996	F-150, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2004 - 2008	F-150, Flareside (New Body Style)	5 min	<u>96-8313</u>	3035-P
Ford	2009 - 2012	F-150, Flareside (New Body Style)	20 min	<u>96-3036</u>	3036-P
Ford	2004 - 2008	F-150, Styleside (New Body Style)	5 min	<u>96-8313</u>	3035-P
Ford	2009 - 2012	F-150, Styleside (New Body Style)	20 min	<u>96-3036</u>	3036-P
Ford	1997	F-250 Heavy Duty, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	1997 - 1999	F-250 Light Duty, Styleside	5 min	<u>96-8313</u>	3035-P

Ford	1999 - 2004	F-250 Super Duty, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2005 - 2007	F-250 Super Duty, All Styles	5 min	<u>55-3065</u>	3065-P
Ford	2008 - 2012	F-250 Super Duty, All Styles	20 min	<u>96-3034</u>	3034-P
Ford	1994 - 1996	F-250, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	1997	F-350 Heavy Duty, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2005 - 2007	F-350 Super Duty Cab & Chassis, All Styles	5 min	<u>55-3065</u>	3065-P
Ford	2008 - 2011	F-350 Super Duty Cab & Chassis, All Styles	20 min	<u>96-3034</u>	3034-P
Ford	1999 - 2004	F-350 Super Duty, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2005 - 2007	F-350 Super Duty, All Styles	5 min	<u>55-3065</u>	3065-P
Ford	2008 - 2012	F-350 Super Duty, All Styles	20 min	<u>96-3034</u>	3034-P
Ford	1994 - 1996	F-350, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	1999 - 2004	F-450 Super Duty Cab & Chassis, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2005 - 2007	F-450 Super Duty Cab & Chassis, All Styles	5 min	<u>55-3065</u>	3065-P
Ford	2008 - 2011	F-450 Super Duty Cab & Chassis, All Styles	20 min	<u>96-3034</u>	3034-P
Ford	2008 - 2012	F-450 Super Duty, All Styles	20 min	<u>96-3034</u>	3034-P
Ford	1999 - 2004	F-550 Super Duty Cab & Chassis, All Styles	5 min	<u>96-8313</u>	3035-P
Ford	2005 - 2007	F-550 Super Duty Cab & Chassis, All Styles	5 min	<u>55-3065</u>	3065-P
Ford	2008 - 2011	F-550 Super Duty Cab & Chassis, All Styles	20 min	<u>96-3034</u>	3034-P
Ford	2012	Flex, w/Factory Tow Package	20 min	<u>96-3036</u>	3036-P
Ford	2009 - 2011	Flex, w/Factory Tow Package	5 min	<u>96-8313</u>	3035-P
Ford	1995 - 2003	Windstar, w/Factory Tow Package	5 min	<u>96-8313</u>	3035-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
GMC	2007 - 2012	Acadia, w/Factory 7-Way	5 min	<u>96-3026</u>	3026-P
GMC	1999 - 2002	Pickup, Sierra, All Styles	5 min	<u>96-8318</u>	3025-P

GMC	2003 - 2006	Pickup, Sierra, All Styles	5 min	<u>96-3015</u>	3015-P
GMC	2007	Pickup, Sierra, Classic Only	5 min	<u>96-3015</u>	3015-P
GMC	2003 - 2006	Yukon Denali, All Styles	5 min	<u>96-3015</u>	3015-P
GMC	2001 - 2002	Yukon Denali, New Body Style w/Amber Turn Signals	5 min	<u>96-8318</u>	3025-P
GMC	2001 - 2002	Yukon XL Denali, All Styles	5 min	<u>96-8318</u>	3025-P
GMC	2003 - 2006	Yukon XL Denali, All Styles	5 min	<u>96-3015</u>	3015-P
GMC	2000 - 2002	Yukon XL, All Styles	5 min	<u>96-8318</u>	3025-P
GMC	2003 - 2006	Yukon XL, All Styles	5 min	<u>96-3015</u>	3015-P
GMC	2003 - 2006	Yukon, All Styles	5 min	<u>96-3015</u>	3015-P
GMC	2000 - 2002	Yukon, New Body Style w/Amber Turn Signals	5 min	<u>96-8318</u>	3025-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Honda	2006 - 2012	Ridgeline, w/Factory Tow Package	5 min	<u>55-7286</u>	3070-P
Honda	2009 - 2012	Pilot, w/Factory Tow Package	5 min	<u>55-7286</u>	3070-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Hummer	2003 - 2007	H2, All Styles	5 min	<u>96-3015</u>	3015-P
Hummer	2005 - 2007	H2 SUT, All Styles	5 min	<u>96-3015</u>	3015-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Infiniti	2004 - 2011	QX56, All Styles	5 min	<u>55-3051</u>	3050-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Jeep	2011 - 2012	Grand Cherokee, w/Factory Tow Package	5 min	N/A	3045-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Kia	2009 - 2011	Borrego, All Styles	5 min	96- <u>3023</u>	3032-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Land Rover	2012	Range Rover Evoque, All Styles	5 min	96- <u>8313</u>	3035-P
Land Rover	2005 - 2009	LR3, All Styles	5 min	96- <u>8313</u>	3035-P
Land Rover	2005 - 2011	Range Rover, Inc. Sport	5 min	96- <u>8313</u>	3035-P
Land Rover	2010 - 2011	LR4, All Styles	5 min	96- <u>8313</u>	3035-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Lexus	2003 - 2007	LX 470, All Styles	5 min	55- <u>3040</u>	3040-P
Lexus	2003 - 2009	GX 470, All Styles	5 min	55- <u>3040</u>	3040-P
Lexus	2008 - 2011	LX 570, All Styles	5 min	55- <u>3040</u>	3040-P
Lexus	2010 - 2011	GX 460, All Styles	5 min	55- <u>3040</u>	3040-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Lincoln	1998 - 2011	Navigator, All Styles	5 min	96- <u>8313</u>	3035-P
Lincoln	2006 - 2008	Mark LT, All Styles	5 min	96- <u>8313</u>	3035-P
Lincoln	2010 - 2012	MKT, w/Factory Tow Package	5 min	96- <u>8313</u>	3035-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Mercury	2002 - 2010	Mountaineer, w/Factory Tow Package	5 min	96- <u>8313</u>	3035-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Nissan	2004 - 2012	Titan Pickup, All Styles	5 min	<u>55-3051</u>	3050-P
Nissan	2004 - 2012	Armada, All Styles	5 min	<u>55-3051</u>	3050-P
Nissan	2005 - 2012	Frontier Pickup, All Styles	5 min	<u>55-3051</u>	3050-P
Nissan	2005 - 2012	Pathfinder, All Styles	5 min	<u>55-3051</u>	3050-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Saturn	2007 - 2009	Outlook, w/Factory 7-Way	5 min	<u>96-3026</u>	3026-P

<b>Make</b>	<b>Year</b>	<b>Model</b>	<b>Inst.Time</b>	<b>Part #</b>	<b>Mfg. #</b>
Toyota	2003 - 2011	LandCruiser, All Styles	5 min	<u>55-3040</u>	3040-P
Toyota	2003 - 2011	Sequoia, All Styles	5 min	<u>55-3040</u>	3040-P
Toyota	2003 - 2011	4Runner, All Styles	5 min	<u>55-3040</u>	3040-P
Toyota	2003 - 2012	Tundra, All Styles	5 min	<u>55-3040</u>	3040-P
Toyota	2007 - 2012	Tacoma Pickup, All Styles	5 min	<u>55-3040</u>	3040-P