







**CHEVY/GMC/CADILLAC**

Part #	CIPA #	Mirror Style	Vehicles	Years
<a href="#"><u>92-1125</u></a>	10000 (LH or RH)		GMC/Chevy Pickups and Vans <i>*will not fit Chrome mirrors with Black trim</i> <i>*Fits Chrome manual mirrors only</i>	1980-1995
<a href="#"><u>92-1126</u></a>	11000 (LH or RH)		Chevy S-10, S-15 <i>*Fits the chrome door-mount two-point break-away style mirror only</i>	1982-1993
<a href="#"><u>92-9188 (LH)</u></a> <a href="#"><u>92-9189 (RH)</u></a> <a href="#"><u>92-1880 (Both)</u></a>	10201 - left 10202 - right 10200 - pair		GMC/Chevy Full-size C/K body style Pickups Suburban, Yukon, Kodiak, Dually, Tahoe Safari, Astro Vans Cadillac Escalade	1988-2000 1992-1999 1991-2004 1992-1999
<a href="#"><u>92-1206 (LH)</u></a> <a href="#"><u>92-1207 (RH)</u></a> <a href="#"><u>92-1884 (Both)</u></a>	10801 - left 10802 - right 10800 - pair		Chevy/GMC Silverado, Sierra Tahoe, Suburban, Yukon, Yukon XL, Denali, Escalade Chevy Avalanche <i>*will not fit Full-Chrome mirrors or telescopic mirrors</i> <i>*will not fit mirrors w/ signal</i> <i>*Fits both Black and Chrome cap models</i>	1999-2006 2000-2006 2000-2006
<a href="#"><u>92-2032 (LH)</u></a> <a href="#"><u>92-2033 (RH)</u></a> <a href="#"><u>92-2031 (Both)</u></a>	10901 - left 10902 - right 10900 - pair		Chevy/GMC Silverado, Sierra Tahoe, Suburban, Yukon, Yukon XL, Denali, Escalade Chevy Avalanche Cadillac Escalade <i>*will not fit telescopic mirrors</i>	2007-2011 2007-2011 2007-2011 2007-2011

**FORD/LINCOLN**

<p><a href="#"><u>92-1126</u></a></p>	<p>11000 (LH or RH)</p>		<p>Ford Full-Size Pickups 1983-1998  Ford Ranger 1983-1991  <i>*Fits the chrome door-mount two-point break-away style mirror only</i></p>
<p><a href="#"><u>92-9186</u></a> (LH)  <a href="#"><u>92-9187</u></a> (RH)  <a href="#"><u>92-1863</u></a> (Both)</p>	<p>11501 - left  11502 - right  11500 - Pair</p>		<p>Ford Full-size Pickups 1992-1997  Ford Aerostar 1990-1997  Ford Explorer, Navajo, Bronco 1988-1995  Ford Bronco 1992-1996  Ford F-250 &amp; F-350 HD w/old body style 1997  <i>*Fits full-Black, Black w/ Chrome cap *Add'l adapter needed for Explorer</i></p>
<p><a href="#"><u>92-9210</u></a> (LH)  <a href="#"><u>92-9211</u></a> (RH)  <a href="#"><u>92-1889</u></a> (Both)</p>	<p>11601 - left  11602 - right  11600 - pair</p>		<p>Ford F-150/F-250 Light Duty 1997-2004  Ford Expedition 1997-2002  Lincoln Navigator 1997-2002  <i>*Fits contour-style only *Does not fit mirrors w/ signal  *Does not fit XLT models *Does not fit 2004 new-style pickups</i></p>
<p><a href="#"><u>92-1218</u></a> (LH)  <a href="#"><u>92-1219</u></a> (RH)  <a href="#"><u>92-1886</u></a> (Both)</p>	<p>11701 - left  11702 - right  11700 - pair</p>		<p>Ford Full-size Light Duty (manual only) 1997-2002  <i>*Fits rectangular-style mirror only</i></p>
<p><a href="#"><u>92-1127</u></a> (LH)  <a href="#"><u>92-1128</u></a> (RH)  <a href="#"><u>92-1887</u></a> (Both)</p>	<p>11801 - left  11802 - right  11800 - pair</p>		<p>Ford F-150 &amp; F-250 Light Duty 2004-2011  Ford F-150 &amp; F-250 XLT Models 2004-2011  <i>*Will not fit STX style mirrors</i></p>
<p><a href="#"><u>92-1775</u></a> (LH)  <a href="#"><u>92-1776</u></a> (RH)  <a href="#"><u>92-1888</u></a> (Both)</p>	<p>11901 - left  11902 - right  11900 - pair</p>		<p>Ford F-250 &amp; F-350 Super Duty 1997-2008  Ford Excursion 2000-2008</p>

**DODGE**

<p><a href="#"><u>92-1125</u></a>      10000 (LH or RH)</p>		<p>Dodge Pickups and Vans  * 1986-93 fits both electric &amp; manual Chrome mirrors  * 1994-95 fits Chrome manual mirrors only</p> <p>1986-1995</p>
<p><a href="#"><u>92-1129</u></a>      10300 (LH or RH)</p>		<p>Dodge Pickups and Vans  * 1994-97 Fits both electric &amp; manual Black mirrors  * 1996-97 Fits chrome electric mirrors  *Will not fit Dodge Dakotas with black sport mirrors</p> <p>1994-1997</p>
<p><a href="#"><u>92-1195 (LH)</u></a>      10501 - left  <a href="#"><u>92-1197 (RH)</u></a>      10502 - right  <a href="#"><u>92-1848 (Both)</u></a>      10500 - Pair</p>		<p>Dodge Old Style 1500,2500,3500  Dodge Durango  Dodge Dakota  Dodge Full-size Van  *will not fit 5"x7" Sport Mirror size</p> <p>1994-2002  1998-2003  1998-2004  2000-2003</p>
<p><a href="#"><u>92-0701 (LH)</u></a>      10701 - left  <a href="#"><u>92-0702 (RH)</u></a>      10702 - right  <a href="#"><u>92-1849 (Both)</u></a>      10700 - pair</p>		<p>Dodge Ram 1500  Dodge Ram 2500 &amp; 3500  *will not fit extendable mirrors on 3500's</p> <p>2002-2006  2003-2006</p>
<p><b>Toyota</b></p>		
<p><a href="#"><u>92-0301 (LH)</u></a>      11301 - left  <a href="#"><u>92-0302 (RH)</u></a>      11302 - right  <a href="#"><u>92-0300 (Both)</u></a>      11300 - pair</p>		<p>Toyota Tundra</p> <p>2007-2011</p>
<p><b>Universal Clip-On Mirrors</b>      <a href="#"><u>Return to top</u></a></p>		
<p><a href="#"><u>92-1777</u></a>      11960</p>		<p>Most Vehicles</p> <p>Any</p>

<p><a href="#"><u>92-1132</u></a>      11953</p>		<p>Most Vehicles</p> <p>Any</p>
<p><a href="#"><u>92-1130</u></a>      30-0096 (not CIPA)</p>		<p>Most Vehicles</p> <p>Any</p>