



## **TOOLS REQUIRED:**

(2) 9/16" wrench or socket • (2) 7/16" wrench or socket



Remove the existing steps.



MORryde



Install box support brackets on each side of the step cavity using the included hardware. Ensure that the support brackets are an equal distance from the side of the unit. Tighten the bolts.





Prepare the box by installing  $\frac{1}{2} - 20 \times 1\frac{1}{2}$ " long full-threaded bolts and jam nut into the rivet nut on each side of the box.



Above. Beyond. Always.

574.293.1581 • MORryde.com



## **STORAGE BOX**

INSTALLATION INSTRUCTIONS

## Step 4

Slide the box into the cavity and let it rest on the support brackets.





There are four holes in the bottom of the box that will align with slots on the support brackets. The different slots allow for varying widths of the mounting plates in the step cavity. Align the holes with the slots in the support plates and install the hardware.





Adjust the box so that it's flush with the side of the unit, or positioned slightly towards the inside of the step cavity, and tighten the bolts

**WARNING:** If the box extends past the side of the unit, the StepAbove steps may contact the box when in the down position.





Once the box is installed, adjust the bolts at the top of the box from the inside of the step cavity outward so that the heads make contact with the support brackets, restricting side to side movement of the storage box. Once the bolts are tightly in place and the box feels solid and isolated from movement, tighten the jam nuts against the rivet nuts in the box to lock the bolts in place.





Above. Beyond. Always.

574.293.1581 • MORryde.com