



Combined RSS Application Guide

Following are the applications for the Roadmaster Suspension Solutions family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

Roadmaster Inc. 6110 NE 127th Ave. Vancouver, WA 98682 1-800-669-9690 Fax: 503-288-8900
 www.roadmasterinc.com

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
BEAVER	MISC		89-94	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
CHEVROLET	P Series	P30/P32/P3500	69-07	1109-116	Stage 1 susp. Kit. 1 5/8 diam. Front bar w/ poly bushing kit for 1 3/4 stock rear bar. Coil spring IFS (not for widebody).	No		1.5	51
						Bar Replaces Factory Sway Bar			
	P Series	P30/P32/P3500	68-99	4109-109	Poly bushing kit for front 1 1/4 stock bar.	No		0.5	5.2
	P Series	P30/P32/P3500	68-99	4109-106	Poly bushing kit for rear 1 3/4 stock bar.	No		0.5	5
	P SERIES	P30/P32/P3500	98-06	RSSCP30	REFLEX STEERING STABILIZER RSSCP30 (REPLACEMENT FOR OEM DAMPER).	No		1	
	P SERIES	P30/P32/P3500	98-06	RSDP30	REFLEX STEERING STABILIZER RSDP30 (REPLACEMENT FOR OEM DAMPER ONLY. NO RETURN TO CENTER FEATURE).	No		1	
	P SERIES	P30/P32/P3500	81-06	RBK3	REFLEX STEERING STABILIZER (UNIT NEEDED RSSP30). Coil spring IFS (not for widebody).	No		1	
	P72-P92		96-97	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
COUNTRY COACH	Intrigue		94-98	RBK10	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
DODGE	M-300/M-500		73-81	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F53 Class A		00-16	4139-300	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 3/8 OEM bar.		No	1	3
	F53 Class A	V10	98-05	TRAC V-10B	Front Trac Bar		No	1	31
	F53 Class A	V10	00-16	RBK9	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	F53 Class A	V10	08-16	RBK22	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA). Recommended for 26,000 lb GVW chassis and any F53 chassis where clearance between Ford's OE trac bar and the Steering Stabilizer may not be adequate with RBK9.	1	No	1.0	
	F53 Class A	V8	88-98	TRAC F53	Front Trac Bar		No	1	25
	F53 Class A	V8	89-08	RBK4	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	F53 Class A	V8 and V10	92-16	4139-127	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	3	No	0.5	3
	F53 Class A	V8 and V10	92-16	4139-125	Rear poly bushing kit for OEM bar, some endlink parts may not be used. 1 1/2 OEM bar.	3	No	1	3
	F53 Class A	V8 and V-10	99-16	1139-140	Front sway bar 1 3/4 diameter. Front factory replacement.		No	1	50
									Bar Replaces Factory Sway Bar
	F550 Class A		00-16	4139-300	Rear poly bushing kit for OEM bar - some endlink parts may not be used. 1 3/8 OEM bar.		No	1	3
	F550 Class A	V10	98-05	TRAC V-10B	Front Trac Bar		No	1	31
	F550 Class A	V10	00-16	RBK9	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F550 Class A	V10	08-16	RBK22	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA). Recommended for 26,000 lb GVW chassis and any F53 chassis where clearance between Ford's OE trac bar and the Steering Stabilizer may not be adequate with RBK9.	1	No	1.0	
	F550 Class A	V8	88-98	TRAC F53	Front Trac Bar		No	1	25
	F550 Class A	V8	89-08	RBK4	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	F550 Class A	V8 and V10	92-16	4139-127	Front poly bushing kit for OEM bar. 1 5/8 OEM bar.	3	No	0.5	3
	F550 Class A	V8 and V10	92-16	4139-125	Rear poly bushing kit for OEM bar, some endlink parts may not be used. 1 1/2 OEM bar.	3	No	1	3
	F550 Class A	V8 and V-10	99-16	1139-140	Front sway bar 1 3/4 diameter. Front factory replacement.		No	1	50
									Bar Replaces Factory Sway Bar
FREIGHTLINER	FRED		07-08	1209-129	Front sway bar 1 3/4 diameter factory replacement.	61	No	1.5	54
									Bar Replaces Factory Sway Bar
	FRED		07-08	1209-130	Rear sway bar auxiliary 1 1/2 diameter.	61	Yes	2.5	89
	XC Chassis	Air Suspension Only	95-98	1209-105	Rear sway bar 1 1/2 diameter (for chassis w/ long 3/4 diameter u-bolts).	5,41	Yes	2.5	89
	XC Chassis	Air Suspension Only	99-03	1209-115	Rear sway bar 1 1/2 diameter (for chassis w/ short 7/8 diameter u-bolts).	5,45	Yes	3.0	89
GMC	P SERIES	P30/P32/P3500	98-06	RSSCP30	REFLEX STEERING STABILIZER RSSCP30 (REPLACEMENT FOR OEM DAMPER).		No	1	
	P Series	P30/P32/P3500	69-07	1109-116	Stage 1 susp. Kit. 1 5/8 diam. Front bar w/ poly bushing kit for 1 3/4 stock rear bar. Coil spring IFS (not for widebody).		No	1.5	51
									Bar Replaces Factory Sway Bar
	P Series	P30/P32/P3500	68-99	4109-109	Poly bushing kit for front 1 1/4 stock bar.		No	.5	5.2

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	P SERIES	P30/P32/P3500	98-06	RSDP30	REFLEX STEERING STABILIZER RSDP30 (REPLACEMENT FOR OEM DAMPER ONLY. NO RETURN TO CENTER FEATURE).	No		1	
	P SERIES	P30/P32/P3500	81-06	RBK3	REFLEX STEERING STABILIZER (UNIT NEEDED RSP30). Coil spring IFS (not for widebody).	No		1	
	P72-P92		96-97	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
JOHN DEERE	Motorhome Chassis		86-88	1169-144	Front sway bar 1 5/8 diameter.	Yes		2.5	87
	Motorhome Chassis		86-94	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
MAGNUM	BEAVER COACHES		94-06	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
	SAFARI VELVET RIDE		98-07	RBK10	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
	SAFARI WITH LEAF SPRINGS		94-07	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
MERCEDES-BENZ	M2		03-16	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
MONACO	LaPalma	Diesel Engine Only	05-10	1259-108	Rear sway bar 1 1/2 diameter.	Yes		3	112
	LAPALMA	DIESEL ENGINE ONLY	05-10	1259-109	Rear sway bar 1 3/4 diameter. For 33 feet and longer.	Yes		3	112
NEWELL	NON-IFS		78-90	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
OSHKOSH	K-LINE		80-95	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
OSHKOSH	M-LINE		80-95	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	TORSION SUSPENSION		94	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	Z-LINE		80-95	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
ROADMASTER	AIR RIDE		00-16	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	MONACO	EXCEPT DANA SPICER FRONT AXLE	00-16	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	STRAIGHT AXLE LEAF SPRING		00-09	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
SPARTAN	EC200	P-LINE	93-07	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	EXP CHASSIS		00-04	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	MC 2000	Air Suspension Only	96-06	1149-125	Front sway bar 1 5/8 diameter.	37	No	2	74
	MC 2000	Air Suspension Only	96-03	1149-1055	Front sway bar 1 5/8 diameter.		Yes	2.5	63
	MC 2000	Air Suspension Only	95-03	1149-106	Rear sway bar 1 5/8 diameter.	2, 58	No	2	81
	MOUNTAIN MASTER	NON INDEPENDENT FRONT SUSPENSION	93-07	RBK7	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	N-LINE		91-07	RBK7	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
SPARTAN	Verst Chassis	Air Suspension Only	97-03	1149-118	Rear sway bar 1 1/2 diameter No bar connecting air bags.	39	Yes	2	104
	Verst Chassis	Air Suspension Only	04-06	1149-119	Rear sway bar 1 1/2 diameter. No bar connecting air bags.	36	Yes	2	108
	Verst Chassis	Air Suspension Only	95-03	1149-106	Rear sway bar 1 5/8 diameter. 4" square tube connecting air bags.	2, 58	No	2	81
	Verst Chassis	Air Suspension Only	97-03	1149-118	Rear sway bar 1 1/2 diameter No bar connecting air bags.	35	Yes	2	104
	Verst Chassis	Air Suspension Only	04-06	1149-119	Rear sway bar 1 1/2 diameter. No bar connecting air bags.	36	Yes	2	108
	Verst Chassis	AIR SUSPENSION ONLY	07-08	1149-121	Rear sway bar 1 1/2 diameter. No bar connecting air bags. Jacks located to rear of cross member.	56	Yes	2	115
	WC SERIES		99-06	RBK7	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No		1
WORKHORSE	P SERIES	P30/P32/P3500	00-05	RSSCP30	REFLEX STEERING STABILIZER RSSCP30 (REPLACEMENT FOR OEM DAMPER).		No		1
	P SERIES	P30/P32/P3500	00-05	RSDP30	REFLEX STEERING STABILIZER RSDP30 (REPLACEMENT FOR OEM DAMPER ONLY. NO RETURN TO CENTER FEATURE).		No		1
	P Series	Spreader bar	00-05	1109-200	Front sway bar stiffener; widetrack only.		No	1	25
	P SERIES	WITHOUT OEM STEERING DAMPER	00-05	RBK3	REFLEX STEERING STABILIZER (UNIT NEEDED RSSP30). Coil spring IFS (not for widebody).		No		1
	R SERIES	NON-INDEPENDENT FRONT SUSPENSION	03-07	RBK13	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No		1
	W Series Chassis	W16, W18, W20, W22, W24	00-12	TRAC W-22	Front Trac Bar. Fits gas models only. Will not fit W20D models.		No	1	28

Class A Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
WORKHORSE	W SERIES CHASSIS	W16,W18	06-12	RBK12	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	W Series Chassis	W16/W18	05-09	1259-115	Front sway bar 1 5/8 diameter.		Yes	2	87
	W Series Chassis	W16/W18	05-09	1259-118	Rear sway bar 1 1/2 diameter.	51	Yes	3	112
	W Series Chassis	W16/W18	05-09	1259-116	Combination front sway bar 1 5/8 diameter and front Trac Bar.		Yes	3.5	117
	W Series Chassis	W20, W22, W24	00-09	1259-105	Front sway bar 1 5/8 diameter.		No	2	87
	W Series Chassis	W20, W22, W24	00-09	1259-108	Rear sway bar 1 1/2 diameter.	55	Yes	3	112
	W Series Chassis	W20, W22, W24	00-09	590054-00	Supplemental brackets for use when Ride Rite air bags are present. Welded application.		No	2	10
	W Series Chassis	W20, W22, W24 Chassis	00-09	1259-106	Front sway bar 1 5/8 diameter. Front trac bar combination.		Yes	3.5	110
	W SERIES CHASSIS	W20,W22,W24	00-12	RBK13	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	W SERIES CHASSIS	W20D	09-10	1259-107	Front bar 1 5/8 diameter.		Yes	2	87
	W SERIES CHASSIS	W22 & W24	00-09	1259-109	Rear sway bar 1 3/4 diameter. For 33 feet and longer.	55	Yes	3	112

Class A Motorhomes 18-22,000 GVWR

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
-------------	--------------	---------------------	-------------	---------------	-----------------	--------------	-----------------	------------	------------

Class A Motorhomes 18-22,000 GVWR

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F53 Class A	V10	06-16	1139-145	Rear sway bar AUX 1 1/2". Requires shock mounts that have two holes and are parallel to the ground.		Yes	1.5	89
	F550 Class A	V10	06-16	1139-145	Rear sway bar AUX 1 1/2". Requires shock mounts that have two holes and are parallel to the ground.		Yes	1.5	89

Class A Motorhomes 24,000 GVW and up

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F53 Class A	V8 AND V-10	12-16	1139-148	Front sway bar 1 3/4 diameter. Front factory replacement.		No	1	50
	F53 Class A	V8 AND V-10	12-16	1139-149	Rear sway bar AUX 1 1/2. Retains factory sway bar.	52	No	2	85
	F550 Class A	V8 AND V-10	12-16	1139-148	Front sway bar 1 3/4 diameter. Front factory replacement.		No	1	50
	F550 Class A	V8 AND V-10	12-16	1139-149	Rear sway bar AUX 1 1/2. Retains factory sway bar.	52	No	2	85

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F53 Class A	V10	88-16	1139-144	Fits same apps as 1139-143. Rear 1 3/4" Heavy Duty Aux. Retains factory swaybar.	52	Yes	2	89
	F550 Class A	V10	88-16	1139-144	Fits same apps as 1139-143. Rear 1 3/4" Heavy Duty Aux. Retains factory swaybar.	52	Yes	2	89

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
-------------	--------------	---------------------	-------------	---------------	-----------------	--------------	-----------------	------------	------------

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F53 Class A	V8 and V10	88-16	1139-143	Rear sway bar AUX 1 1/2". Retains factory sway bar.	52	Yes	2	85
	F550 Class A	V8 and V10	88-16	1139-143	Rear sway bar AUX 1 1/2". Retains factory sway bar.	52	Yes	2	85

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	2500 Class C		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Class C		97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	2500 Class C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Class C	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	2500 Class C	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	2500 Class C	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	2500 Class C	Van & Cutaway	97-16	590150-00	Rear replacement end link kit only.		No	.5	5
	2500 Class C	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	2500 Cutaway	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	2500 Cutaway	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	3500 Class C		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Class C		77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	3500 Class C	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	3500 Class C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Class C	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Class C	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Class C	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Class C	Van & Cutaway	04-16	590150-00	Rear replacement end link kit only.		No	.5	5
	3500 Class C	Van & Cutaway	97-16	590150-00	Rear replacement end link kit only.		No	.5	5
	3500 Class C	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
	3500 Class C	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Cutaway	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	3500 PICKUP SILVERADO	Pickup Cab (except HD)	86-98	1109-137	Front sway bar 1 3/8 diameter (2WD) only.		No	1	32
	4500 Class C	Van & Cutaway	08-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	4500 Class C	Van & Cutaway	08-16	590150-00	Rear replacement end link kit only.		No	.5	5
	4500 Class C	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
	4500 Class C	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	4500 Class C	Van & Cutaway	08-16	590150-00	Rear replacement end link kit only.		No	.5	5
	G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.		No	1	37
	G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.		Yes	1.5	41
	Kodiak C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.		No	2	52
	Kodiak C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	57, 59, 62	No	2.5	55
	KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.		Yes	.5	5
	KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.		No	.5	5
	Kodiak C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.		No	2	52

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	Kodiak C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	57, 59, 62	No	2.5	55
	KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.		Yes	.5	5
	KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.		No	.5	5
DODGE	B250	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter.	15	Yes	1.5	48
	B350	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter.	15	Yes	1.5	48
	SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	63	No	1	25
									Bar Replaces Factory Sway Bar
	SPRINTER 2500	2500	08-16	1209-128	Rear swaybar 1 1/8 diameter factory replacement.	70	No	1	25
									Bar Replaces Factory Sway Bar
	Sprinter 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	63	No	1	27
									Bar Replaces Factory Sway Bar
	SPRINTER 3500	3500	08-16	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	63	No	1	40
									Bar Replaces Factory Sway Bar
	SPRINTER 3500	3500	07-16	1209-131	Rear Aux sway bar 1 1/2 diameter retains factory bar.	71	Yes	2.5	60
	SPRINTER 3500	3500	04-06	1209-132	Rear Aux sway bar 1 1/2 diameter retains factory bar.		Yes	2.5	60
FORD	E250		09-16	1139-176	Front sway bar 1 3/8 diameter.		No	1	36
									Bar Replaces Factory Sway Bar
	E250	Class C	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	2	42
									Bar Replaces Factory Sway Bar

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	E250	Class C	92-10	590233-00	Front replacement end link kit only.	No	.5	5	
	E250	VAN	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	1.5	42
									Bar Replaces Factory Sway Bar
	E250	VAN	92-10	590233-00	Front replacement end link kit only.	No	.5	5	
	E350		75-91	1139-100	Front sway bar 1 3/8 diameter.	18	No	1.5	37
	E350		09-16	1139-176	Front sway bar 1 3/8 diameter.		No	1	36
									Bar Replaces Factory Sway Bar
	E350	Class C	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	2	42
									Bar Replaces Factory Sway Bar
	E350	Class C	75-14	1139-117	Rear sway bar 1 1/2 diameter.	Yes	1.5	53	
	E350	Class C	92-10	590233-00	Front replacement end link kit only.	No	.5	5	
	E450		09-16	1139-176	Front sway bar 1 3/8 diameter.		No	1	36
									Bar Replaces Factory Sway Bar
	E450		97-08	1139-115	Front sway bar 1 3/8 diameter.	22	No	2	42
									Bar Replaces Factory Sway Bar
	E450		97-16	1139-147	Rear sway bar 1 1/2 diameter.	27	Yes	1	47
									Bar Replaces Factory Sway Bar
	E450		97-16	590147-00	Rear replacement end link kit only.	No	.5		
	E450		97-16	590233-00	Front replacement end link kit only.	No	.5	5	

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F450		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	
	F450		08-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	32	No	1	38
	F550 Class C		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	32	No	1	38
	F550 Class C		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	55
	F550 Class C		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	
	F550 Class C		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	
	F550 Class C		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	
	F550 Class C		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	32	No	1	38
	F550 Class C	Cutaway	05-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	30	No	1	48
	F550 Class C	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	30	No	1.5	48
FREIGHTLINER	SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	63	No	1	25
	SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	63	No	1	27
	SPRINTER 3500	3500	07-16	1209-131	Rear Aux sway bar 1 1/2 diameter retains factory bar.	71	Yes	2.5	60

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	2500 Class C		04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	2500 Class C	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	2500 Class C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Class C	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	2500 Class C	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	2500 Class C	Van & Cutaway	97-16	590150-00	Rear replacement end link kit only.		No	.5	5
	2500 Class C	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Class C		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Class C	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	3500 Class C	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Class C	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Class C	Van & Cutaway	07-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Class C	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	3500 Class C	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Class C	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Class C	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
									Bar Replaces Factory Sway Bar
	3500 Class C	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 PICKUP SIERRA	Pickup Cab (except HD)	86-98	1109-137	Front sway bar 1 3/8 diameter (2WD) only.		No	1	32
	4500 Class C	Van & Cutaway	08-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	4500 Class C	Van & Cutaway	08-16	590150-00	Rear replacement end link kit only.		No	.5	5
	4500 Class C	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	4500 Class C	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
									Bar Replaces Factory Sway Bar
	4500 Class C	Van & Cutaway	08-16	590150-00	Rear replacement end link kit only.		No	.5	5
	4500 Cutaway	Van & Cutaway	08-16	590150-00	Rear replacement end link kit only.		No	.5	5
	G30	CLASS C CUTAWAY	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.		No	1	37

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.		Yes	1.5	41
	Kodiak C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8" diameter.		No	2	52
	Kodiak C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	57, 59, 62	No	2.5	55
	KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.		No	.5	5
	KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.		Yes	.5	5
	Kodiak C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8" diameter.		No	2	52
	Kodiak C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	57, 59, 62	No	2.5	55
	KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.		No	.5	5
	KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.		Yes	.5	5
MERCEDES-BENZ	SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	63	No	1	25
									Bar Replaces Factory Sway Bar
	SPRINTER 2500	2500	08-16	1209-128	Rear sway bar 1 1/8 diameter factory replacement.	70	No	1	25
									Bar Replaces Factory Sway Bar
	SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	63	No	1	27
									Bar Replaces Factory Sway Bar
	SPRINTER 3500	3500	08-16	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	63	No	1	40
									Bar Replaces Factory Sway Bar

Class C Motorhomes

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
MERCEDES-BENZ	SPRINTER 3500	3500	07-16	1209-131	Rear Aux sway bar 1 1/2 diameter retains factory bar.	71	Yes	2.5	60
	SPRINTER 3500	3500	04-06	1209-132	Rear Aux sway bar 1 1/2 diameter retains factory bar.		Yes	2.5	60
WORKHORSE	3500 Class C	Cutaway	07-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Class C	Cutaway	07-16	590150-00	Rear replacement end link kit only.		No	.5	5
	4500 Class C	Cutaway	07-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50

Cutaways/Vans

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	2500 Cutaway	Cutaway	95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Cutaway	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Cutaway	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Cutaway	Cutaway	95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Cutaway	Van & Cutaway	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	3500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Cutaway	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43

Cutaways/Vans

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	3500 Cutaway	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.	No	.5	5	
	3500 Cutaway	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	No		1	
	4500 Cutaway	Cutaway	08-16	590150-00	Rear replacement end link kit only.	No	.5	5	
	4500 Cutaway	Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	No		1.5	
						Bar Replaces Factory Sway Bar			
	4500 Cutaway	Van & Cutaway	08-16	1109-149	Front sway bar 1 1/2 factory replacement.	Yes	1.5	85	
	4500 Cutaway	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	G30	CLASS C CUTAWAY	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	No		1	
	Kodiak C4500	Cutaway	03-10	TRAC 45-5500	Front Trac Rod	54	No	1.5	27
	Kodiak C4500	Cutaway	03-10	RBK5	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
	Kodiak C5500	Cutaway	03-10	TRAC 45-5500	Front Trac Rod	54	No	1.5	27
	Kodiak C5500	Cutaway	03-10	RBK5	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
FORD	E450	V-10	87-16	RBK11	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC).	No		1	
	E450	V8 WITH OEM STEERING DAMPER	87-16	RBK11	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	No		1	

Cutaways/Vans

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	E450	V8 WITHOUT OEM STEERING DAMPER	87-16	RBK2	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	No		1	
FREIGHTLINER	AIR SUSPENSION	SOLID FRONT AXLE	06-16	RBK18	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	10
	AIR SUSPENSION	SOLID FRONT AXLE	95-05	RBK14	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA) Note: does not fit models with 150 gallon fuel tank.	No		1	
GILLIG	DIESEL MODELS		94-06	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
	GAS MODELS		86-94	RBK6	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)	No		1	
GMC	2500 Cutaway	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	No		1	
	2500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.	Yes		1.5	85
	2500 Cutaway	Van & Cutaway	04-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	2500 Cutaway	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	2500 Cutaway	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.	No		.5	5
	2500 Cutaway	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	No		1	
	3500 Cutaway	Cutaway	95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)	No		1	
	3500 Cutaway	Cutaway	77-16	590150-00	Rear replacement end link kit only.	No		.5	5

Cutaways/Vans

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	3500 Cutaway	Cutaway	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	3500 Cutaway	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Cutaway	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Van	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	4500 Cutaway	Cutaway	04-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	4500 Cutaway	Van & Cutaway	08-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	Kodiak C4500		03-10	TRAC 45-5500	Front Trac Rod	54	No	1.5	27
	Kodiak C4500	Cutaway	03-10	RBK5	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	Kodiak C5500	Cutaway	03-10	TRAC 45-5500	Front Trac Rod	54	No	1.5	27
	Kodiak C5500	Cutaway	03-10	RBK5	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	P Series	P30/P32/P3500	68-99	4109-106	Poly bushing kit for rear 1 3/4 stock bar.		No	.5	5
WORKHORSE	3500 Cutaway	Cutaway	07-16	590150-00	Rear replacement end link kit only.		No	.5	5

Cutaways/Vans

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
WORKHORSE	3500 Cutaway	Van & Cutaway	07-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Cutaway	Van & Cutaway	07-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Cutaway	Van & Cutaway	07-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	4500 Cutaway	Van & Cutaway	07-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	2500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Cutaway	Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
	3500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	4500 Cutaway	Van & Cutaway	08-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	4500 Cutaway	Van & Cutaway	08-16	590150-00	Rear replacement end link kit only.		No	.5	5
	4500 Cutaway	Van & Cutaway	08-16	1109-175	Rear sway bar 1 1/2 diameter.	65, 68	Yes	1.5	50
	Kodiak C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	57, 59, 62	No	2.5	55
	Kodiak C4500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxillary bar.		No	2.5	60

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.		Yes	.5	5
	KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.		No	.5	5
	Kodiak C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.		No	2	52
	Kodiak C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxiliary bar.	57, 59, 62	No	2.5	55
	Kodiak C5500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxillary bar.		No	2.5	60
	KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.		Yes	.5	5
	KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.		No	.5	5
	Kodiak C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.		No	2	52
DODGE	4500	Cutaway	08-16	1129-131	Rear sway bar 1 1/2 diameter factory replacement.		No	2	
									Bar Replaces Factory Sway Bar
	5500	Cutaway	08-16	1129-131	Rear sway bar 1 1/2 diameter factory replacement.		No	2	
									Bar Replaces Factory Sway Bar
FORD	F350		11-13	1139-180	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup, cab chassis, SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar
	F350		05-08	1139-156	Front sway bar 1 3/8 diameter, (2WD) only. To replace factory bar.		No	1	48
									Bar Replaces Factory Sway Bar
	F350		08-10	1139-174	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup, cab chassis SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F350	Cutaway	99-12	1139-160	Rear sway bar 1 1/2 diameter. Factory replacement. Round axle tubes. (2WD & 4WD).	31	No	1	37
									Bar Replaces Factory Sway Bar
	F350	Cutaway	05-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	30	No	1	48
									Bar Replaces Factory Sway Bar
	F350	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	30	No	1.5	48
									Bar Replaces Factory Sway Bar
	F450		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	55
									Bar Replaces Factory Sway Bar
	F450		08-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	32	No	1	38
									Bar Replaces Factory Sway Bar
	F450		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	
	F450	Cutaway	86-98	1139-123	Rear sway bar 1 1/2 diameter w/ factory sway bar.	23	Yes	2	35
	F450	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	30	No	1.5	48
									Bar Replaces Factory Sway Bar
	F450	Cutaway	99-06	1139-160	Rear sway bar 1 1/2 diameter. Cab chassis. Factory replacement. Round axle tube.	31	No	1	37
									Bar Replaces Factory Sway Bar
	F550 Truck		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	32	No	1	38
									Bar Replaces Factory Sway Bar
	F550 Truck		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	55
									Bar Replaces Factory Sway Bar
	F550 Truck		11-14	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.		No	1	
	F550 Truck	Cutaway	05-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	30	No	1	48
									Bar Replaces Factory Sway Bar

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F550 Truck	Cutaway	04-07	1139-157	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.	30	No	1.5	48
									Bar Replaces Factory Sway Bar
	F650	Cutaway	09-12	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.		No	2.5	
	F650	Cutaway	09-12	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	67	Yes	2	90
FREIGHTLINER	FL Series	FL50, FL60	91-02	1209-100	Front sway bar 1 1/2 diameter. 8000 lbs. axle only.	38	No	2	51
	FL Series	FL50, FL60	91-02	1209-101	Rear sway bar 1 1/2 diameter - Hendrickson air suspension only.	39	Yes	2.5	89
	FL Series	FL50, FL60	91-02	1209-104	Rear sway bar 1 1/2 diameter - Hendrickson air suspension w/ chains only.	40	Yes	2.5	89
	FL Series	FL50, FL60	91-02	1209-106	Rear sway bar 1 1/2 diameter airline suspension with rear mounting chains. With 5x4 u-bolt pattern.	42	Yes	2.5	90
	FL Series	FL50, FL60	91-02	1209-106SP	Rear sway bar 1 1/2 diameter airline suspension with rear mount Onspot chains already on. With 5x4 u-bolt pattern.		Yes	2	90
	FL Series	FL50, FL60	91-02	1209-107	Rear sway bar 1 1/2 diameter airline suspension without front mounting chains.	43	Yes	2.5	90
	FL Series	FL50,FL60	91-02	RBK8	REFLEX STEERING STABILIZER (UNIT NEEDED RSSA)		No	1	
	FL Series	FL70	91-02	1209-112	Rear sway bar 1 1/2 diameter - Hendrickson air only. With 6x4 u-bolt pattern.		Yes	2.5	89
	FL Series	FL70	91-02	1209-113	Rear sway bar 1 1/2 diameter airline suspension. With 6x4 u-bolt pattern. Will not fit models with optional center fuel tank.	44	Yes	2.5	94
	M2		03-16	1209-106	Rear sway bar 1 1/2 diameter airline suspension with rear mounting chains. With 5x4 u-bolt pattern.	42	Yes	2.5	90

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FREIGHTLINER	M2		03-15	1209-106SP	Rear sway bar 1 1/2 diameter airline suspension with rear mount Onspot chains already on. With 5x4 u-bolt pattern.		Yes	2	90
	M2		03-16	1209-107	Rear sway bar 1 1/2 diameter airline suspension without front mounting chains.	43	Yes	2.5	90
	M2		03-16	1209-113	Rear sway bar 1 1/2 diameter airline suspension. With 6x4 u-bolt pattern. Will not fit models with optional center fuel tank.	44	Yes	2.5	94
	M2		03-16	1209-116	Front sway bar 1 1/2 diameter 8000lbs axle. Will not fit w/ Mercedes engine auxillary cooling package.	46	No	2	50
	Sterling		05-06	1209-119	Front sway bar 1 1/2 diameter.		No	2	50
GMC	2500 Cutaway	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	2500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	2500 Cutaway	Van & Cutaway	04-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Cutaway	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
	3500 Cutaway	Van & Cutaway	04-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	4500 Cutaway	Van & Cutaway	04-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	4500 Cutaway	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.	No		1.5	
						Bar Replaces Factory Sway Bar			
	4500 Cutaway	Van & Cutaway	08-16	590150-00	Rear replacement end link kit only.	No		.5	5
	4500 Cutaway	Van & Cutaway	08-16	1109-149	Front sway bar 1 1/2 factory replacement.	Yes		1.5	85
	Kodiak C4500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	No		2	52
	Kodiak C4500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxillary bar.	No		2.5	60
	Kodiak C4500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxillary bar.	57, 59	No	2.5	55
						,62			
	KODIAK C4500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	No		.5	5
	KODIAK C4500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Yes		.5	5
	Kodiak C5500	Cutaway	03-10	1109-158	Front sway bar 1 5/8 diameter.	No		2	52
	Kodiak C5500	Cutaway	03-10	1109-157	Rear sway bar 1 5/8 facing rear auxillary bar.	57, 59	No	2.5	55
						,62			
	Kodiak C5500	Cutaway	03-10	1109-174	FOR USE WITH GRANNING AIR RIDE ONLY! 1 5/8 diameter rear facing rear auxillary bar.	No		2.5	60
	KODIAK C5500	Cutaway	03-10	590065-00	Replacement rear end link kit only.	No		.5	5
	KODIAK C5500	Cutaway	03-10	590066-00	Replacement front end link kit only.	Yes		.5	5

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
INTERNATIONAL	32/43/4400 Series		03-16	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	67	Yes	2	90
	32/43/4400 Series		03-16	590060-00	Rear axle plate kit for applications without Onspot chains.		No	.5	42
							Bar Replaces Factory Sway Bar		
	32/43/4400 SERIES	Low Profile and Standard Chassis	03-16	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.		No	2.5	
	4700 LP Series		89-02	1179-100	Front sway bar 1 1/2 diameter.		No	2	63
	4700 LP Series		89-02	1179-101	Rear sway bar 1 1/2 diameter with Navistar factory air ride only.		Yes	2.5	86
	Durastar		03-16	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	67	Yes	2	90
	Durastar	Low Profile and Standard Chassis	03-16	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.		No	2.5	
	Terrastar		12-15	1179-124	Front bar.		No	2	73
	Terrastar		12-16	1179-112	Rear bar. Have to purchase 590060-00 if not using auto chains.		Yes	2	90
NAVISTAR	32/43/4400 Series		03-16	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	67	Yes	2	90
	32/43/4400 Series		03-16	590060-00	Rear axle plate kit for applications without Onspot chains.		No	.5	42
							Bar Replaces Factory Sway Bar		
	32/43/4400 SERIES	Low Profile and Standard Chassis	03-16	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.		No	2.5	
	4700 LP Series		89-02	1179-101	Rear sway bar 1 1/2 diameter with Navistar factory air ride only.		Yes	2.5	86

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
NAVISTAR	4700 LP Series		89-02	1179-100	Front sway bar 1 1/2 diameter.	No	2	63	
	Durastar		03-16	1179-110	Rear sway bar 1 5/8 diameter with Onspot chains only, will work with air brakes. LIMITED GROUND CLEARANCE.	67	Yes	2	90
	Durastar	Low Profile and Standard Chassis	03-16	1179-121	Front sway bar 1 1/2 diameter for Standard & LP Chassis 8,000lb & 10,000lb axle. Low Profile.	No		2.5	
	Terrastar		12-16	1179-124	Front bar.	No	2	73	
	Terrastar		12-16	1179-112	Rear bar. Have to purchase 590060-00 if not using auto chains.	Yes	2	90	
STERLING	4500	Cutaway	08-12	1129-131	Rear sway bar 1 1/2 diameter factory replacement.	No	2		
						Bar Replaces Factory Sway Bar			
	5500	Cutaway	08-12	1129-131	Rear sway bar 1 1/2 diameter factory replacement.	No	2		
						Bar Replaces Factory Sway Bar			

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	2500 Cutaway	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Cutaway	Van & Cutaway	97-16	590150-00	Rear replacement end link kit only.	No	.5	5	
	G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.	No	1	37	
	G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.	Yes	1.5	41	
	W4500	Cutaway	08-09	1109-172	Rear sway bar 1 1/2 diameter for Tilt Cab Chassis.	Yes	2	80	

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>	
DODGE	4500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.	No	1	40	Bar Replaces Factory Sway Bar	
	4500	Cutaway	13-16	1129-138	Front sway bar 1 5/8 diameter factory replacement.	No	1	40	Bar Replaces Factory Sway Bar	
	5500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.	No	1	40	Bar Replaces Factory Sway Bar	
	5500	Cutaway	13-16	1129-138	Front sway bar 1 5/8 diameter factory replacement.	No	1	40	Bar Replaces Factory Sway Bar	
	B200	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter for cut-aways.	15	Yes	1.5	48	
	B300	Cutaway	75-03	1129-111	Rear sway bar 1 3/8 diameter for cut-aways.	15	Yes	1.5	48	
FORD	E250		09-14	1139-176	Front sway bar 1 3/8 diameter.	No	1	36	Bar Replaces Factory Sway Bar	
	E250	Cutaway	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	1.5	42	Bar Replaces Factory Sway Bar
	E250	Cutaway	92-10	590233-00	Front replacement end link kit only.	No	.5	5		
	E350		09-16	1139-176	Front sway bar 1 3/8 diameter.	No	1	36	Bar Replaces Factory Sway Bar	
	E350	Cutaway	75-91	1139-100	Front sway bar 1 3/8 diameter motorhomes cut-aways.	18	No	1.5	37	
	E350	Cutaway	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	1.5	42	Bar Replaces Factory Sway Bar
	E350	Cutaway	75-16	1139-117	Rear sway bar 1 1/2 diameter motorhomes cut-aways.	Yes	1.5	53		

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	E350	Cutaway	75-09	1139-108	Rear sway bar 1 3/8 diameter (w/ automatic chains). Rear facing.	20	Yes	1.5	44
	E350	Cutaway	75-09	590108-00	Rear replacement end link kit only.		No	.5	5
	E350	Cutaway	92-10	590233-00	Front replacement end link kit only.		No	.5	5
	E450		97-16	1139-147	Rear sway bar: 1 1/2 diameter.	27	Yes	1	47
									Bar Replaces Factory Sway Bar
	E450		09-16	1139-176	Front sway bar 1 3/8 diameter.		No	1	36
									Bar Replaces Factory Sway Bar
	E450		97-16	590147-00	Rear replacement end link kit only.		No	.5	
GMC	2500 Cutaway	Van & Cutaway	97-16	590150-00	Rear replacement end link kit only.		No	.5	5
	2500 Cutaway	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Cutaway	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Cutaway	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Cutaway	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	4500 Cutaway	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	G30	Cutaway	75-96	1109-131	Front sway bar 1 3/8 diameter.		No	1	37

Emergency Vehicles

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	G30	Cutaway	75-96	1109-121	Rear sway bar 1 1/4 diameter.		Yes	1.5	41
	W4500	Cutaway	08-09	1109-172	Rear sway bar 1 1/2 diameter for Tilt Cab Chassis.		Yes	2	80
STERLING	4500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.		No	1	40
							Bar Replaces Factory Sway Bar		
	5500	Cutaway	08-12	1129-134	Front sway bar 1 5/8 diameter factory replacement.		No	1	40
							Bar Replaces Factory Sway Bar		

Passenger Vans

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	2500 Van	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
GMC	2500 Van	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	3500 Van	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30

SUVs

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CADILLAC	Escalade		00-16	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	48	Yes	1	36
							Bar Replaces Factory Sway Bar		
CHEVROLET	Avalanche		00-08	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	48	Yes	1	36
							Bar Replaces Factory Sway Bar		
	Suburban	1500	92-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	11	No	1.5	34

SUVs

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	Suburban	1500	92-99	1109-142	Rear sway bar 1 1/8 diameter (w/ factory bar).	10	No	1.5	23
									Bar Replaces Factory Sway Bar
	Suburban	1500	00-08	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	48	Yes	1	36
									Bar Replaces Factory Sway Bar
	Suburban	2500	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	12	Yes	1	28
	Tahoe	1500	95-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	11	No	1.5	34
	Tahoe	1500	00-14	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	48	Yes	1	36
									Bar Replaces Factory Sway Bar
	Tahoe	1500	95-99	1109-142	Rear sway bar 1 1/8 diameter (w/ factory bar).	10	No	1.5	23
									Bar Replaces Factory Sway Bar
	Tahoe	2500 XL	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	12	Yes	1	28
DODGE	Durango		04-08	1129-126	Rear sway bar 1" diameter factory replacement.		No	0.5	40
									Bar Replaces Factory Sway Bar
FORD	Excursion		00-05	1139-155	Front sway bar 1 1/2 diameter.	29	No	1.5	40
	Excursion		00-05	1139-154	Rear sway bar 1 3/8 diameter.		Yes	1.5	45
	Excursion	4WD	00-05	RBK16	REFLEX STEERING STABILIZER (UNIT NEEDED RSSB)		No	1	
	Expedition		97-03	1139-150	Rear sway bar 1 1/8 diameter.		No	1	23
									Bar Replaces Factory Sway Bar
GMC	Suburban	1500	00-08	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	48	Yes	1	36
									Bar Replaces Factory Sway Bar

SUVs

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	Suburban	2500	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	12	Yes	1	28
	Yukon	1500	00-14	1109-168	Rear sway bar 1 1/8 diameter (w/factory bar).	48	Yes	1	36
	Yukon	1500	95-99	1109-144	Rear sway bar 1 1/8 diameter (w/o factory bar).	11	No	1.5	34
	Yukon	1500	95-99	1109-142	Rear sway bar 1 1/8 diameter (w/factory bar).	10	No	1.5	23
	Yukon	2500 XL	00-08	1109-160	Rear sway bar 1 1/4 diameter (leaf spring suspension).	12	Yes	1	28
JEEP	Rubicon		04-08	1129-132	Rear sway bar 1 1/8 diameter factory replacment.		No	1.5	30

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	1500 PICKUP SILVERADO	2 WHEEL DRIVE	98-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	1500 PICKUP SILVERADO	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	13	Yes	1.5	40
	1500 PICKUP SILVERADO	Standard & HD	09-09	1109-176	Rear sway bar 1" diameter (2WD & 4WD).		Yes	1.5	28
	1500 PICKUP SILVERADO	STANDARD & HD	10-16	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	8	Yes	1.5	
	1500 PICKUP SILVERADO	Standard & HD	00-08	590045-00	For rear extended endlinks for vehicles with 4 lift kit installed.		No	0.5	10
	1500 Van		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	1500 Van	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	1500 Van	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Cutaway	Van & Cutaway	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	2500 PICKUP SILVERADO	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	13	Yes	1.5	40
	2500 PICKUP SILVERADO	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Duallys, 2500 & 3500.		Yes	1	45
	2500 PICKUP SILVERADO	STANDARD & HD	10-16	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	8	Yes	1.5	
	2500 PICKUP SILVERADO	Standard & HD	00-09	590045-00	For rear extended endlinks for vehicles with 4 lift kit installed.		No	0.5	10
	2500 Van		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Van	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Van	Van	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	2500 Van	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	2500 Van	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	2500 Van	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	3500 PICKUP SILVERADO	Standard & HD	00-07	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD) and dually.	13	Yes	1.5	40
	3500 PICKUP SILVERADO	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Dualys, 2500 & 3500.		Yes	1	45
								Bar Replaces Factory Sway Bar	
	3500 PICKUP SILVERADO	Standard & HD	00-07	590045-00	For rear extended endlinks for vehicles with 4 lift kit installed.		No	0.5	10
	3500 PICKUP SILVERADO	Standard & HD	08-09	1109-171	Rear sway bar 1 1/4 diameter SRW (4WD) and Dually.	8	Yes	1.5	47
	3500 PICKUP SILVERADO	STANDARD & HD	10-16	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	8	Yes	1.5	
	3500 Van		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Van	2500 & 3500 Passenger Van	97-16	1109-148	Rear sway bar 1" diameter.		Yes	1.5	30
	3500 Van	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Van	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Van	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Van	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Van	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	3500 Van	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
								Bar Replaces Factory Sway Bar	

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
CHEVROLET	3500 Van	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
DODGE	1500 Pickup Ram	Pick-up Ram	09-16	1129-135	Rear sway bar 1 1/8 diameter factory replacement (4WD).		No	1	25
									Bar Replaces Factory Sway Bar
	1500 Pickup Ram	Pick-up Ram	96-02	590053-00	Poly bushing kit for front factory bar.		No	0.5	10
	2500 Pickup Ram		03-08	RBK20	Replaces Factory Dampener (UNIT NEEDED RSSB)	64	No	1.5	
									Bar Replaces Factory Sway Bar
	2500 Pickup Ram	Pick-up Ram	96-02	1129-122	Rear sway bar 1 1/4 diameter (4WD).	17	No	1.5	31
									Bar Replaces Factory Sway Bar
	2500 Pickup Ram	PICK-UP RAM	03-13	1129-124	Rear sway bar 1 1/4 diameter (4WD) will fit single and dually.	16, 69	No	1.5	
	2500 Pickup Ram	Pick-up Ram	96-02	590052-00	Poly bushing kit for front factory bar.		No	0.5	10
	2500 Pickup Ram	Pick-up Ram	99-02	1129-136	Front sway bar 1 1/2 diameter factory replacement.		No	1	40
									Bar Replaces Factory Sway Bar
	3500 Pickup Ram	Pick-up Ram	96-02	1129-122	Rear sway bar 1 1/4 diameter (4WD).	17	No	1.5	31
									Bar Replaces Factory Sway Bar
	3500 Pickup Ram	PICK-UP RAM	03-06	1129-124	Rear sway bar 1 1/4 diameter (4WD) will fit single and dually.	16, 69	No	1.5	
	3500 Pickup Ram	PICK-UP RAM	10-13	1129-124	Rear sway bar 1 1/4 diameter (4WD) fits single only.	69	No	1.5	
	3500 Pickup Ram	Pick-up Ram	07-09	1129-130	Rear sway bar 1 3/8 diameter for dually and single rear wheel.		No	1.5	41
	3500 Pickup Ram	Pick-up Ram	07-08	1129-133	Rear sway bar 1 3/8 diameter for (2WD) Dually pickup only.		Yes	1.5	80

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
DODGE	3500 Pickup Ram	Pick-up Ram	03-06	1129-137	Rear sway bar 1 1/4 diameter (2WD) will fit single and dually.		No	1.5	31
	3500 Pickup Ram	Pick-up Ram	10-14	1129-130	Rear sway bar 1 3/8 diameter for Dually Pick-ups only.		No	1.5	41
	3500 Pickup Ram	PICK-UP RAM	03-08	RBK20	Replaces Factory Dampener (UNIT NEEDED RSSB)	64	No	1.5	
									Bar Replaces Factory Sway Bar
	B200	Passenger Van	75-03	1129-107	Rear sway bar 1" diameter.	14	Yes	1.5	34
	B300	(conversion van only) 1 ton	75-03	1129-111	Rear sway bar 1 3/8 diameter.	15	Yes	1.5	48
	B300	Passenger Van	75-03	1129-107	Rear sway bar 1" diameter.	14	Yes	1.5	34
	Sprinter 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	63	No	1	25
									Bar Replaces Factory Sway Bar
	SPRINTER 2500	2500	08-16	1209-128	Rear swaybar 1 1/8 diameter factory replacement.	70	No	1	25
									Bar Replaces Factory Sway Bar
	SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	63	No	1	27
									Bar Replaces Factory Sway Bar
	SPRINTER 3500	3500	08-16	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	63	No	1	40
									Bar Replaces Factory Sway Bar
FORD	E250	V8 WITH OEM STEERING DAMPER	87-16	RBK11	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	E250	V8 WITHOUT OEM STEERING DAMPER	87-16	RBK2	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	E350	Van	75-06	1139-134	Rear sway bar 1 1/8 diameter for auto chains.	24	Yes	1.5	35

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	E350	Van	75-06	1139-109	Rear sway bar 1 3/8 diameter.	21	Yes	1.5	51
	E350	V-10	87-16	RBK11	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	E350	V8 WITH OEM STEERING DAMPER	89-16	RBK11	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	E350	V8 WITHOUT OEM STEERING DAMPER	87-16	RBK2	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	E350	VAN	92-10	1139-115	Front sway bar 1 3/8 diameter.	22	No	1.5	42
									Bar Replaces Factory Sway Bar
	E350	VAN	00-16	1139-178	Rear sway bar 1 1/2 diameter (2WD) Class B Motorhome.		Yes	1.5	53
	E350	VAN	92-10	590233-00	Front replacement end link kit only.		No	.5	5
	F150		04-06	1139-152	Rear sway bar 1 1/8 diameter (4WD).		No	1	48
	F150		08-16	1139-177	Rear sway bar 1 1/8 diameter (2WD & 4WD).		Yes	1.5	40
	F250		11-16	1139-180	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup and cab chassis SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar
	F250		99-03	1139-155	Front sway bar 1 1/2 diameter (4WD).	29	No	1	40
	F250		99-03	1139-153	Rear sway bar 1 3/8 diameter F250 & F350 factory replacement bar. No Dually. If no factory swaybar present, see note 28.	28	Yes	1.5	34
									Bar Replaces Factory Sway Bar
	F250		99-07	1139-165	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	33	No	1	29
									Bar Replaces Factory Sway Bar

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F250		08-16	1139-173	Rear sway bar 1 3/8 diameter factory replacement (4WD & 2WD). No factory bar, please see note 66.	66	No	1.5	40
									Bar Replaces Factory Sway Bar
	F250		04-07	1139-170	Rear sway bar 1 3/8 diameter.		No	1.5	49
									Bar Replaces Factory Sway Bar
	F250		04-07	1139-158	Front sway bar 1 3/8 diameter, (4WD) with coil spring only.		No	1	48
									Bar Replaces Factory Sway Bar
	F250		05-08	1139-156	Super Duty front sway bar 1 3/8 diameter sway bar (2WD) only. To replace factory bar.		No	1	48
									Bar Replaces Factory Sway Bar
	F250		08-10	1139-174	Super Duty front sway bar 1 3/8 diameter factory replacement (2WD & 4WD) pickup, cab chassis SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar
	F250	4WD	99-07	RBK16	REFLEX STEERING STABILIZER (UNIT NEEDED RSSB)		No	1	
	F350		12-13	1139-168	Front sway bar 1 3/8 diameter factory replacement (2WD) cab chassis.		No	1.0	45
									Bar Replaces Factory Sway Bar
	F350		04-07	1139-158	Front sway bar 1 3/8 diameter for coil spring only, (4WD) only.		No	1	48
									Bar Replaces Factory Sway Bar
	F350		04-07	1139-170	Rear sway bar 1 3/8 diameter.		No	1.5	49
									Bar Replaces Factory Sway Bar
	F350		11-16	1139-180	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup, cab chassis, SRW and dually.		No	1	45
									Bar Replaces Factory Sway Bar
	F350		99-07	1139-165	Rear sway bar 1 1/2 diameter F250 & F350 (dually).	33	No	1	29
									Bar Replaces Factory Sway Bar
	F350		99-03	1139-153	Rear sway bar 1 3/8 diameter F250 & F350 factory replacement bar. No Dually. If no factory swaybar present, see note 28.	28	Yes	1.5	34
									Bar Replaces Factory Sway Bar
	F350		99-03	1139-155	Front sway bar 1 1/2 diameter (4WD).	29	No	1	40

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FORD	F350		05-08	1139-156	Front sway bar 1 3/8 diameter, (2WD) only. To replace factory bar.	No	1	48	Bar Replaces Factory Sway Bar
	F350		08-16	1139-173	Rear sway bar 1 3/8 diameter factory replacement (4WD & 2WD). No factory bar, please see note 66.	66	No	1.5	40 Bar Replaces Factory Sway Bar
	F350		08-10	1139-174	Front sway bar 1 3/8 diameter factory replacement (4WD) pickup, cab chassis SRW and dually.	No	1	45	Bar Replaces Factory Sway Bar
	F350	4WD	99-07	RBK16	REFLEX STEERING STABILIZER (UNIT NEEDED RSSB)	No	1		
	F450		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	No	1		
	F450		08-10	590055-00	Front and rear polyurethane bushings to replace factory rubber bushings.	No	1	5	
	F450		08-10	1139-171	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	No	1	55	Bar Replaces Factory Sway Bar
	F450		08-11	1139-175	Rear sway bar 1 1/2 diameter. Fits (4WD) SRW & Dually Pickups.	No	1.5	35	Bar Replaces Factory Sway Bar
	F550 Truck		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	No	1		
	F550 Truck		11-16	1139-179	Front sway bar 1 1/2 diameter (2WD & 4WD) cab chassis F450-F550.	No	1		
	F550 Truck		00-16	1139-161	Rear sway bar 1 1/2 diameter. Factory replacement. Square axle tubes.	32	No	1	38 Bar Replaces Factory Sway Bar
FREIGHTLINER	Sprinter 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	63	No	1	25 Bar Replaces Factory Sway Bar
	SPRINTER 2500	2500	08-16	1209-128	Rear swaybar 1 1/8 diameter factory replacement.	70	No	1	25 Bar Replaces Factory Sway Bar

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
FREIGHTLINER	SPRINTER 3500	3500	08-16	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	63	No	1	40
									Bar Replaces Factory Sway Bar
	SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	63	No	1	27
									Bar Replaces Factory Sway Bar
GMC	1500 PICKUP SIERRA	2 WHEEL DRIVE	98-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	1500 PICKUP SIERRA	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	13	Yes	1.5	40
	1500 PICKUP SIERRA	Standard & HD	09-09	1109-176	Rear sway bar 1" diameter (2WD & 4WD).		Yes	1.5	28
	1500 PICKUP SIERRA	Standard & HD	00-08	590045-00	For rear extended endlinks for vehicles with 4 lift kit installed.		No	0.5	10
	1500 PICKUP SIERRA	STANDARD & HD	10-16	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	8	Yes	1.5	
	1500 Van		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	1500 Van	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	1500 Van	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 PICKUP SIERRA	Standard & HD	00-09	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD)	13	Yes	1.5	40
	2500 PICKUP SIERRA	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Dualys, 2500 & 3500.		Yes	1	45
									Bar Replaces Factory Sway Bar
	2500 PICKUP SIERRA	Standard & HD	00-09	590045-00	For rear extended endlinks for vehicles with 4 lift kit installed.		No	0.5	10

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	2500 PICKUP SIERRA	STANDARD & HD	10-16	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	8	Yes	1.5	
	2500 Van		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Van	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	2500 Van	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	2500 Van	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	2500 Van	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	2500 Van	WITH DUAL CROSS MEMBERS	04-13	RBK17	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 PICKUP SIERRA	Standard & HD	08-09	1109-171	Rear sway bar 1 1/4 diameter SRW (4WD) and Dually.	8	Yes	1.5	47
	3500 PICKUP SIERRA	Standard & HD	00-09	1109-166	Front Sway bar 1 1/2 diameter factory replacement (2WD & 4WD) Duallys, 2500 & 3500.		Yes	1	45
									Bar Replaces Factory Sway Bar
	3500 PICKUP SIERRA	Standard & HD	00-07	1109-167	Rear sway bar 1 1/4 diameter (2WD & 4WD) and dually.	13	Yes	1.5	40
	3500 PICKUP SIERRA	Standard & HD	00-07	590045-00	For rear extended endlinks for vehicles with 4 lift kit installed.		No	.5	10
	3500 PICKUP SIERRA	STANDARD & HD	10-16	1109-169	Rear sway bar 1 1/4 diameter (2WD & 4WD).	8	Yes	1.5	
	3500 Van		95-04	RBK15	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
GMC	3500 Van	STEERING BOX OUTSIDE FRAME	71-95	RBK1	REFLEX STEERING STABILIZER (UNIT NEEDED RSSC)		No	1	
	3500 Van	Van & Cutaway	77-16	590150-00	Rear replacement end link kit only.		No	.5	5
	3500 Van	Van & Cutaway	97-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Van	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Van	Van & Cutaway	04-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85
	3500 Van	Van & Cutaway	97-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Van	Van & Cutaway	08-16	1109-173	Rear sway bar 1 1/2 diameter factory replacement. Not for use with Auto-Chains.		No	1.5	
	4500 Cutaway	Van & Cutaway	04-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
MERCEDES-BENZ	SPRINTER 2500	2500	02-07	1209-117	Rear sway bar 1 1/8 diameter.	63	No	1	25
	SPRINTER 2500	2500	08-16	1209-128	Rear sway bar 1 1/8 diameter factory replacement.	70	No	1	25
	SPRINTER 3500	3500	04-07	1209-118	Rear sway bar 1 3/8 diameter.	63	No	1	27
	SPRINTER 3500	3500	08-16	1209-120	Rear sway bar 1 3/8 diameter factory replacement.	63	No	1	40
NISSAN	Titan		07-12	1189-101	Rear sway bar 1 1/8 diameter.		Yes	1	30

<u>Make</u>	<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Notes</u>	<u>Drilling</u>	<u>Tim</u>	<u>Wt.</u>
TOYOTA	Tundra		07-12	1189-102	Rear sway bar 1.0 diameter.		Yes	1	40
WORKHORSE	3500 Van	Cutaway	07-16	1109-150	Rear sway bar 1 3/8 diameter.	68	Yes	1.5	43
	3500 Van	Cutaway	07-16	1109-175	Rear sway bar 1 1/2 diameter.	68	Yes	1.5	50
	3500 Van	Cutaway	07-16	590150-00	Rear replacement end link kit only.		No	.5	5
	3500 Van	Van & Cutaway	07-16	1109-149	Front sway bar 1 1/2 factory replacement.		Yes	1.5	85

Application Guide Notes Key

- 1 · Modification may be required.
- 2 · Welding required.
- 3 · 1992 to mid-1995 have IPD-style bars with rubber bushings. Mid-1995 on have IPD-style bars with urethane bushings.
- 4 · 18,000 lbs. GVWR and under.
- 5 · Will not fit Newmar motorhomes.
- 6 · Not for Oshkosh X, V, M or T line chassis (check with manufacturer for your model using VIN#).
- 7 · 1991 and older require factory retro fit conversion kit.
- 8 · Will Work with air bags.
- 9 · With autochains and with and without air brake.
- 10 · Will fit 1992-99 models with 4WD. For vehicles with factory sway bar for Suburban and 4 door Tahoe/Yukon – not for 2 door models.
- 11 · Will fit 1999 models. For vehicles without factory bar. For Suburban and 4-door Tahoe/Yukon. Not for 2 door models.
- 12 · For 2000-on GMC Yukon XL and Chevy Suburban (leaf springs 2500/3500 series) not for “regular” Yukon or Tahoe (coil springs – 1500 series).
- 13 · For 2000-on Chevy/GMC 2500, 2500HD and 3500 (fits both single and dual rear wheels) pickups. Both gas and Duramax diesels. Will work with airbags.
- 14 · Fits 80-2003 3/4 ton and 1 ton vans.
- 15 · For 1975-03 Motor home chassis can be used on heavily loaded 1 ton vans.
- 16 · 2003-06 Dodge 4WD pickups 2500 and 3500 models, both single and dual rear wheels. For stock ride height vehicles. May not fit with 5th wheel hitch.
- 17 · 1996-02 4WD 2500 and 3500 pickups. Not designed for 2WD.
- 18 · For 1975-91 only. Not for E150.
- 19 · Fits 1975-2006 Motor homes and emergency vehicles. Will still work on 2005 gas E-series van cutaways.
- 20 · For E350 DRW (dual rear wheels/cutaway) chassis 1975-2003 with automatic chains. Nor for use on diesel or V-10 models.
- 21 · For 1975-2003 Ford E350 vans without chains. Type 2 Ambulance or Class B Motor home.
- 22 · 1992-2006 also fits E-Super Duty, sometimes called E450. This kit has offset endlinks for tie rod clearance. Does not fit E250 or E150.
- 23 · For 1988-91 F53 motor home chassis. Not for 1992 or newer motor homes. Also F450 pickup cab/chassis. 1986-97 to replace factory sway bar if not factory bar, additional parts will be needed (see Ford Dealer).
- 24 · For 1992 models and newer vans (Type 2 Ambulance/Class B Motor Homes) except Powerstroke diesels and V-10 models. The exhaust is in the way! Kit could be mounted if customer is willing to modify exhaust.
- 25 · For V-8 chassis and V-10 chassis with GVWR of 18,000lbs or less. The 4th digit of the VIN is L or M. GVWR is found on chassis data plate/sticker. These axle U-bolts are spaced 5” wide by 5.25” front to rear (Dana 80 axle). Will work with a tag axle if the drive axle has leaf springs.
- 26 · For 1998-on F53 with V-10 engine and GVWR greater than 18,000 lbs. The 4th digit of VIN is N. GVWR is found on chassis data plate/sticker. U-bolt spacing is 5” wide by 6.25” front to back (Dana S135 rear axle). Will work with a tag axle if the drive axle has leaf springs.
- 27 · Will work on the new 6 liter diesel engine for E450 chassis 1997-on. Mounts to axle same as factory bar and will work with chains. Replaces 1139-137. This bar has vertical forged ends.
- 28 · For 1999-2003 F250/350 pickup single rear wheels with factory sway bar (both 2WD and 4WD). Replaces factory bar. If no factory bar endlinks will be needed (#590230-00) need 1 per vehicle. Will not fit 2004 or any dual rear wheels. Bar mounts under differential, not over differential like stock sway bar.
- 29 · Front sway bar kit for 2000-04 Ford F250-F350 trucks with straight axle (all 4WD models and F450 with front leaf springs, and F550 2WD models). Replaces factory sway bar. Must have factory sway bar. Will not fit 2005-on with coil spring front suspension. Updated to exclude 1999 models. Will fit 1999 model when factory bar is present (added 1/2” hardware for 99 model year)
- 30 · Front sway bar kit for 2005-on Ford F450-F550 4WD trucks with coil spring axle. Replaces factory sway bar. Must have factory sway bar. Will only fit cabin chassis, not for pickups.

- 31 · Rear sway bar kit replaces factory sway bar. For F350 commercial cab/chassis (only Dana 80 rear end with shock bracket welded to axle). Will not fit any pickup. On F450 confirm Dana 80 axle (round axle tubes). If axle tubes are square (Dana 120) use kit #1139-161.
- 32 · Rear sway bar for 2000-08 F550 cab/chassis. Replaces factory bar. Also fits F450 with Dana 120 axle (square axle tubes).
- 33 · Rear sway bar for 1999-2007 F250 & F350 2WD and 4WD pickups with dual rear wheels and factory sway bar. Designed to replace factory sway bar. Not for lifted trucks.
- 34 · For chassis with true air brakes with air canister on the axle. Some chassis have air assist brakes or air over hydraulic brakes, these are not true air brakes.
- 35 · Rear sway bar kit for Spartan Verst, air suspension. 1996-on 1.5" diameter. Will not fit Renegade made by Harney Coach. Leveling jacks are in the way.
- 36 · For Spartan Verst air suspension. 2004-on.
- 37 · Fits Mountain Master M11 Verst Chassis.
- 38 · For FL series chassis with 8,000lbs front axle and 19.5" rims or 126" wheel height. Normally used on FL50 or FL60 series low profile trucks (most ambulance chassis). This will not work with the new Cat diesel engine introduced in 2000.
- 39 · For FL50 & FL60 ambulance chassis with Hendrickson air ride rear suspension. Will not work with chains (use 1209-104).
- 40 · For Freightliner FL50/FL60 chassis with automatic chains. Proven to fit with Onspot. Arms of bar face towards rear of truck for Hendrickson suspension only.
- 41 · For chassis up to 1998 and some 1999 and newer with long ¾" diameter. U-bolts on rear axle. Have customer or shop measure u-bolt diameter. For chassis with short 7/8" diameter U-bolts (most of 1999-on) use kit #1209-115. If rear suspension does not have U-bolts, we do not have a kit.
- 42 · For 2000-on FL50/FL60 Airliner chassis with Freightliner air suspension 10/12K-15K GVW. If truck has Hendrickson air rear suspension, use #1209-101 or #1209-104 with chains. Bar mounts towards rear of chassis. For use with autochains. Not for Class A motor homes.
- 43 · For FL series Airliner with Freightliner air suspension. Bar mount towards front of chassis. Not for use with chains. If vehicle is equipped with chains, use #1209-106.
- 44 · For Freightliner FL70 with Airliner rear suspension. Rear facing bar.
- 45 · For most 1999-2003 Freightliner XC. This kit is for chassis with short 7/8" diameter bolts on rear axle. NOTE: sometime in 2003 Freightliner suspension changed to a style with No U- bolts. Have customer/shop measure U-bolt diameter. For chassis with ¾" diameter U-bolts (mostly up to 1998) use kit #1209-105. If rear suspension does not have U-bolts (2003-on) we do not have a kit.
- 46 · Will not work on chassis with Mercedes Benz engines that have auxiliary cooling package, if standard cooling, it is okay.
- 47 · Update of kit #1259-106 now fits all years for Rear W22 Workhorse chassis. Also fits W20 chassis.
- 48 · Fits GM 1/2 ton SUV chassis; coil springs only.
- 49 · Will not fit with auto chains
- 50 · Only fits vehicles with gas tanks that are rear of the axle.
- 51 · Currently does not work with Super Hitch
- 52 · Check to insure there is enough factory ubolt available to accommodate the factory nut, washer and our 1/2" plate. If there is not enough ubolt the 590050-00 ubolt replacement kit is needed.
- 53 · If superhitch is installed the 590051-00 bracket kit is needed
- 54 · For use with Duramax diesel will not fit gas engine.
- 55 · When air bags have been added you will need the 590054-00 adapter kit which requires welding.
- 56 · For Spartan Mountain Master Verst air suspension chassis Tuthill 240AR with jacks located to the rear of the cross member.
- 57 · Will work with Kelderman air ride, Will work with Link Ultra ride.
- 58 · Chassis must have 3" square beam connecting the 2 airbags located underneath.
- 59 · Rear Leaf Spring hanger brackets may be bolted or riveted on. When riveted, install time will increase. Manufacture codes can be found under the driver side visor: EV8 = Rivets ; EV9 = Bolts.
- 60 · Will not work with air bags.
- 61 · Must have factory swaybars.
- 62 · When installing with Link UltraRide or Kelderman Air Ride kits, two B315 endlinks will be need to be ordered separately.
- 63 · 2007 Model year vehicles manufactured in or after June may have 2008 Chassis. Please confirm before ordering.
- 64 · Will work with other model years that have the inverted Y front steering system with factory dampener.

- 65 · Will work with automatic tire chains.
- 66 · When no factory bar is present, customer will need to purchase kit 590170-00.
- 67 · For Applications Without onspot chains use 1179-110 and 590060-00.
- 68 · Chassis built before June of 2007 will require an additional axle mounting bracket kit part # 590061-00.
- 69 · Will NOT fit with Goose Neck Hitch.
- 70 · If unit has no sway-bar from factory you will need mount kit 590064-00 (Factory mount kit).
- 71 · Some Airstream chassis have a propane tank inside the frame between the frame and drive line the 1209-131 will not fit with this model (please check before ordering).