

IN EN style™ MC

OUTDOOR
SOLAR PATHWAY LIGHT
LUMINAIRE SOLAIRE
POUR ALLÉE
EXTÉRIEUR



Item# 3606-000

Before returning to Home Hardware: Call Customer Service @ 1-866-349-8665
(Monday-Friday 9a.m.-5p.m. EST)

HOW SOLAR LIGHTS WORK

During the day, the solar panel collects sunlight and converts it into energy to charge the battery. At night, the light automatically turns on using this stored energy.

To activate the light:

Remove the battery tab (located on the underside of the light cap).

The light's duration depends on your location, weather, and sunlight exposure. When fully charged, the light can run for up to 8 hours.

LOCATION AND CHARGING

- Place the solar light where the solar panel gets **at least 6 hours of full, direct sunlight each day**.
- Avoid placing the light in shady spots, as it will reduce battery charge and shorten night-time illumination.
- The light has a built-in sensor that turns it on when it's dark and off when it's bright. To ensure optimal performance, **avoid placing it near other light sources at night**.
- **Ideal placement:** Garden pathways and lawns.

FIRST TIME USE

If the light does not turn on after 6 hours of sunlight, please check:

1. Make sure the **battery tab** has been removed.
2. Ensure the battery is **securely in contact** with the terminals.
3. Confirm the light is placed in an area with **direct sunlight**.

PRECAUTIONS

1. The light is designed to work in **dark surroundings**. If placed near bright lights at night, it may not illuminate or could be very dim.
2. The battery is pre-charged by the manufacturer, but the charge may have decreased during shipping. Please **charge as recommended** for the best performance.
3. Keep the solar panel **clean**, dust or dirt can reduce its ability to charge fully.

BATTERY & LED LIGHT REPLACEMENT

- The **battery lifespan** is up to 18 months. Replace with **AA Ni-MH 1.2V** (battery must state for outdoor use).
- The **LED bulb** lasts for over **100,000 hours**—no replacement needed.