

## QUICK & EASY

- complete attic coverage in as little as 2 hours<sup>†</sup>
- self-feeding system
- puts FIBERGLAS<sup>®</sup> insulation where you want it
- integrated AUTOCUTTER

## SAFE & RELIABLE SYSTEM

- optimized process for minimal handling
- fully enclosed blowing system
- hose-mounted remote control

## VIRTUALLY NO MESS

- FIBERGLAS<sup>®</sup> insulation releases and expands completely inside machine
- provides easy clean-up (machine does the work)
- low-dust system

## VIRTUALLY NO SETTling

- over time, there's virtually no settling of AttiCat<sup>®</sup>
- keeps energy-saving\* R-value, longer

"Worked great insulating our house we just purchased. Old home with very little insulation so we used AttiCat<sup>®</sup> Insulation and it was very easy and worked great!"

*Janine*

Topping up your attic can **save up to 20%** on heating & cooling costs\* Use the AttiCat<sup>®</sup> Expanding Blown-In Insulation System and the job is done in as little as 2 hours<sup>†</sup>

## GET YEAR-ROUND COMFORT WITH PINK<sup>®</sup>

- ✓ 73% recycled content<sup>^</sup>, SCS certified
- ✓ Insulating your attic helps reduce greenhouse gases by up to ½ a ton<sup>\*\*</sup> per year!
- ✓ GREENGUARD Gold Certified and validated to be formaldehyde-free

Share Your Experience at [ReviewAttiCat.ca](https://ReviewAttiCat.ca)

"This is one of the best insulation blowing machines available that I have used that doesn't cost what the larger professional machines do. You also don't need a large truck or trailer to tow it around on!"

*Mitch*

To learn more about Owens Corning<sup>®</sup> products visit [www.owenscorning.ca](https://www.owenscorning.ca)



Subscribe to the **Owens Corning Canada's YouTube channel** for helpful how-to videos.




Follow us on Facebook at [facebook.com/owenscorningcanada](https://facebook.com/owenscorningcanada)



73% PINK<sup>®</sup> FIBERGLAS<sup>®</sup> Insulation

Pub. No. 500860B. Printed in Canada. May 2020. THE PINK PANTHER<sup>™</sup> & © 1964-2020 Metro-Goldwyn-Mayer Studios Inc. All Rights Reserved. The colour PINK is a registered trademark of Owens Corning. © 2020 Owens Corning. \*Heating and cooling costs only. Up to 20% savings based on Hot 2000, Version 8.7 run for a 2 storey 1972 type base house with 1149 sf per floor for an increase from R-8 to R-40 in the attic in Canadian climates. Savings vary depending on original amount of insulation in your home, climate, house size, air leaks, and personal energy use and living habits. \*\*Based on an average attic size of 1700 sf with existing R19 insulation, averaged over 7 cities in Canada. ^73% recycled content is based on the average recycled glass content in all Owens Corning fiberglass batts, rolls and unbonded loosefill insulation manufactured in Canada, SCS certified. †Blowing time, based on attic size 100m<sup>2</sup>/1000ft<sup>2</sup> at RSI 8.8/R-50. \*\*Comparison based on 1,000 sq. ft. coverage of AttiCat<sup>®</sup> Blown-In Insulation (R-20) as compared to blown insulation (R-20) of a leading manufacturer of cellulose insulation.

# ATTICAT<sup>®</sup> INSULATION WORKS HARD, SO YOU DON'T HAVE TO.



## HOW MANY BAGS OF INSULATION ARE REQUIRED?

Refer to the chart below to determine the amount of AttiCat® Insulation you need in your attic. To achieve maximum energy efficiency, an R value of 60 is recommended for most Canadian attics (check local building codes, for more information).



- ✓ Fewer bags required!
- ✓ Compact for easier transport and install

OWENS CORNING RECOMMENDS R-60 - ALL YOU NEED IS 22¼"									
R-VALUE	R-12	R-20	R-24	R-28	R-32	R-36	R-40	R-50	R-60
BLOWN INCHES	4.5	7.5	9.0	10.5	12.0	13.5	14.75	18.5	22.25
COVERAGE/BAG (SQ. FT.)	162.9	97.8	81.5	69.8	61.1	54.3	48.9	39.1	32.6
NUMBER OF 30 LB. ATTICAT® PINK® FIBERGLAS® INSULATION BAGS REQUIRED									
SQ. FT.	R-12	R-20	R-24	R-28	R-32	R-36	R-40	R-50	R-60
500	3.1	5.1	6.1	7.2	8.2	9.2	10.2	12.8	15.3
600	3.7	6.1	7.4	8.6	9.8	11.0	12.3	15.3	18.4
700	4.3	7.2	8.6	10.0	11.5	12.9	14.3	17.9	21.5
800	4.9	8.2	9.8	11.5	13.1	14.7	16.4	20.5	24.5
900	5.5	9.2	11.0	12.9	14.7	16.6	18.4	23.0	27.6
1000	6.1	10.2	12.3	14.3	16.4	18.4	20.4	25.6	30.7
1100	6.8	11.2	13.5	15.8	18.0	20.3	22.5	28.1	33.7
1200	7.4	12.3	14.7	17.2	19.6	22.1	24.5	30.7	36.8
1300	8.0	13.3	16.0	18.6	21.3	23.9	26.6	33.2	39.9
1400	8.6	14.3	17.2	20.1	22.9	25.8	28.6	35.8	42.9
1500	9.2	15.3	18.4	21.5	24.5	27.6	30.7	38.4	46.0
1600	9.8	16.4	19.6	22.9	26.2	29.5	32.7	40.9	49.1
1700	10.4	17.4	20.9	24.4	27.8	31.3	34.8	43.5	52.1
1800	11.0	18.4	22.1	25.8	29.5	33.1	36.8	46.0	55.2
1900	11.7	19.4	23.3	27.2	31.1	35.0	38.9	48.6	58.3
2000	12.3	20.4	24.5	28.7	32.7	36.8	40.9	51.2	61.3

**Estimate project time** It only takes 5 minutes to blow one bag of AttiCat® Insulation! Simply multiply the number of bags you need by 5.

## ATTICAT® MACHINE AND PRODUCT PICK UP

Grab your bags of AttiCat® Expanding Blown-In PINK® FIBERGLAS® Insulation, AttiCat® rulers and head over to the machine rental department to pick up the AttiCat® machine. There, you will receive straight-forward instructions on how to use this innovative system. You're one step closer to reducing your energy\* costs!



## TOOLS REQUIRED

Keep yourself clean and safe with a few inexpensive pieces of protective gear:

**Face Masks** are recommended while insulating. Use a properly fitted NIOSH or MSHA-approved disposable dust respirator, such as the 3M Model 8210 (model 8271, for high-humidity environments) or equivalent.


**Eye Protection, gloves, pants, and a long-sleeve shirt** while insulating helps minimize contact with the material and make for easy cleanup and comfort.

## FOR AN EASY PROCESS!

Though a one-person operation is possible, the process is generally easier and faster with two people — one operating the machine at the source, and another applying AttiCat® Insulation in the attic. This saves hassle and potentially multiple trips up and down a ladder.

### SETUP


**Assemble machine. Run hose to attic.**



### AT THE MACHINE


### USE

**Push half bag into machine.**




### USE

**Push remote "START" button to start machine.**



**Cut bags in half.**



**Removing packaging.**



**Blow insulation to desired depth.**



### IN THE ATTIC