



WOOD RESTORER RTU C11-70

Description

Ready to Use Wood Restorer was developed to perform optimally through the combination of proprietary formulation and development. The cleaner and brightener offers excellent restorative features for exterior wood surfaces.

Recommended Substrates

Wood Surfaces – Vertical and Horizontal Use

Tinting and Base Information

N/A

Features

Ready to Use
Cleaner
Brightener
Restorer of wood
Oxalic Acid Formulation
Home Owners Guarantee

Benefits

Removes Moss
Removes Mill-Glaze
Removes dead wood fibres (grey wood)
Does not contain Bleach

Regulatory Conformance and Approvals

N/A

Technical Data

Vehicle Type: Oxalic Acid

Gloss Range: N/A

Spread Rate: 250-400ft² per gallon depending on age and porosity of surface.

Wet Film Thickness: N/A

Dry Film Thickness: N/A

Spread Rate do not include loss due to surface irregularities, surface porosity, and application method

Volume Solids*: N/A

Weight Solids*: N/A

*N/A

Drying Time: @ 25°C; 50% Relative Humidity

To Touch – N/A

To Recoat – N/A

To Full Cure – N/A

Drying times will vary depending on ambient temperature, humidity, film build, colour, and air movement.

Surface Temperature:

Material – 10°C (50°F) to 32° (90°F)

Ambient - 10°C (50°F) to 32° (90°F)

Substrate - 10°C (50°F) to 32° (90°F)

Storage of material at elevated temperatures for prolonged periods may experience skinning.

Viscosity: N/A

Flash Point: N/A

Disposal: Contact your local environmental regulatory office or your municipality for specific guidelines

Container Sizes:

C11-70 4L 1874R207

General Preparatory Steps and Application Info

- Ready to Use.
- Do not dilute.
- Dampen the wood to be cleaned.
- Spray on solution and scrub lightly with bristle brush.
- Allow cleaning solution to stand for 5-10 minutes and repeat above.
- Rinse the surface thoroughly with a pressure washer (500PSI) or a garden hose.
- Depending on severity of surface, repeat and rinse again.
- Allow surface to dry until moisture content in wood surface is below 15%.
- Surface might need to be sanded due to residual grey wood and/or condition of surface. Do not sand smooth.
- Depending on aggressiveness of cleaning, the wood surface might fir up necessitating a quick sanding. Do not sand smooth.
- Possibly the wood surface is too far gone negating the use of cleaner.
- Do not mix with products containing bleach or ammonia.
- Will not neutralize mold or mildew. Please consult with your local paint department.
- Will remove a majority of mill-glaze but a light sanding (not smooth) is recommended.
- No cleaner in the market will restore surface back to new wood appearance.
- Will not damage or remove paint, stain, or clear finishes off the surface. Try a test spot first to gauge performance.
- Do not apply in direct sunlight.
- Please take extra precaution near and around the project to protect foliage, metal, and glass.
- Not intended to be used on resin or composite material.
- Follow label directives for application requirement. Consult your local Paint Department.
- Stir thoroughly before and occasionally during use.
- Can be used as maintenance cleaner once or twice a year.

Application Equipment: Apply with a garden sprayer and a bristle brush.

Thinning: N/A