



PARTS:



- A gables - (2) 1 1/8" x 6 3/4" x 23 3/4"
- B shelves - (2) 1 1/8" x 6 3/4" x 34 3/8"
- C front piece - (1) 3/4" x 5 1/4" x 38"
- D dividers - (2) 1 1/8" x 6 5/8" x 10 5/8"

Cut two gables to finished size.



Cut dados across the gables.




Band saw arcs in gables.



Cut two shelves to size and machine tenons on their ends.







Sand and assemble shelves and gables.

Cut front piece to size and cut arcs on ends.


On all the pieces, apply masking tape where parts will be glued. This will prevent paint from interfering with the glue joints.



Cut two dividers to size.




Sand and apply finishes to all parts.
Install the two dividers.




Apply glue and clamp the front piece to the cabinet.

Align the bottom of the front piece with the bottom of the shelf.



SIDE VIEW SECTION



Install "L" brackets to the back of the cabinet, aligned with your wall studs.

